


Bouclair

Your Super-Simple Guide to Setting Up Your
Product Number: **GS-F011085-ORB**



CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT AND FULLY INSERT.

Cleaning & Care

Do not use polishes or cleaners on your lamp.
Dust surfaces with a dry soft cloth.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not insert fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not modify the plug.

QUESTIONS? service@bouclair.com – 1 800 268-2524

Assembly

Please read and save these assembly instructions:

Be careful when unpacking the lamp since the wires are connected (if the wires are pulled out of their connectors, it may result in a bad connection.)

1. Lay out all lamp parts from the box and place them on a flat surface.
2. Screw bottom tube (B) onto base (A) clockwise to tighten.
3. Screw tube (C) onto tube (B) clockwise to tighten.
4. Screw tube (D) onto tube (C) clockwise to tighten.
5. Screw tieing (E) onto tube (D) clockwise to tighten.
6. Screw bend tube (I) onto tube (J) clockwise to tighten.
7. Install shade (F) on socket (H) by reattaching ring (G).
8. Use with a maximum 23W CFL bulb (not included) or maximum 100W Type A incandescent bulb (not included).
5. loosen the handle(K), and adjust the assembly to desired position, then re-tighten the handle(K) on the joint.

